Additional Fitting Instructions

Drive Shades are designed to push into the window frame and stay in place without clips. They do this using a spring metal frame that is designed to spring back into position when bent.

Every car has a different shape and design of window so its not possible to give car specific instructions but by following the below guide, it will help you fit your Drive Shades the way that they were designed for. Please read this sheet in conjunction with the pictorial fitting instructions supplied.

* Fit the longest edge first. For example, on a door, it is usually the bottom edge. Follow this by fitting the next longest edge and so on. Try to only bend one side at a time if possible. Sometimes, it may be easier to fit the part of the shade with the sharpest angles first. Experiment and see what works the best.

* Where a shade has a corner with a sharp angle, it may need a little more force to fit it.

* The shades are designed to bend to allow them to be pushed into the window frame. They will spring back into place but care must be taken to not bend them too much otherwise, they may bend permanently

* If you do accidentally bend a shade permanently, sometimes it can be straightened by applying heat using a hair dryer

* It is not recommended that the window is opened more than half way otherwise the shade may fall out, especially at speed where it may be sucked out.